

DW TECH BULLETIN

DOC#: DW08242011

Distribution: Internal and External

These commands are for advanced display control

An will make the Composite VGA, and HDMI ports change and display the information related to these commands

Example Mode Sending the number 9 function command will force the number 9 camera to pop up full screen

INDEX	FUNCTION	START	RS-485 extension code	FUNCTION	Extension code	END	
1	1	0xA2	0x00	0x01	0x01	0xAF	
2	2	0xA2	0x00	0x02	0x01	0xAF	
3	3	0xA2	0x00	0x03	0x01	0xAF	
4	4	0xA2	0x00	0x04	0x01	0xAF	
5	5	0xA2	0x00	0x05	0x01	0xAF	
6	6	0xA2	0x00	0x06	0x01	0xAF	
7	7	0xA2	0x00	0x07	0x01	0xAF	
8	8	0xA2	0x00	0x08	0x01	0xAF	
9	9	0xA2	0x00	0x09	0x01	0xAF	
10	10	0xA2	0x00	0x0A	0x01	0xAF	
11	11	0xA2	0x00	0x0B	0x01	0xAF	
12	12	0xA2	0x00	0x0C	0x01	0xAF	
13	13	0xA2	0x00	0x0D	0x01	0xAF	
14	14	0xA2	0x00	0x0E	0x01	0xAF	
15	15	0xA2	0x00	0x0F	0x01	0xAF	
16	16	0xA2	0x00	0x10	0x01	0xAF	

Communication Specification

* RS232 / RS485

* Baudrate : 2400bps ~ 57.6Kbps

* Start bit : 1bit

* Stop bit : 1bit

* Parity : None

Head Office

5436 W Crenshaw Street Tampa, FL 33634
Toll Free 866-446-3595 FAX 813-888-9262

Sales Office

9551 Irvine Center Dr
Irvine, CA 92618

DW TECH BULLETIN

DOC#: DW08242011

Distribution: Internal and External

These commands are for advanced display control and entering into playback and more complex functions

It will make the Composite VGA and HDMI ports change and display the information related to these commands

Example After Playback is launched, the user can force a Fast Forward or Fast Rewind

37	MUTE	0xA2	0x00	0x2C	0x01	0xAF	FUNCTION
38	FIRST	0xA2	0x00	0x31	0x01	0xAF	FUNCTION
39	BACK_PLAY	0xA2	0x00	0x32	0x01	0xAF	FUNCTION
40	FPLAY	0xA2	0x00	0x33	0x01	0xAF	FUNCTION
41	LAST	0xA2	0x00	0x34	0x01	0xAF	FUNCTION
42	FAST_REW	0xA2	0x00	0x35	0x01	0xAF	FUNCTION
43	FAST_FWD	0xA2	0x00	0x36	0x01	0xAF	FUNCTION
44	PAUSE	0xA2	0x00	0x37	0x01	0xAF	FUNCTION
45	STOP	0xA2	0x00	0x38	0x01	0xAF	FUNCTION
46	CH PLUS	0xA2	0x00	0x41	0x01	0xAF	FUNCTION
47	CH MINUS	0xA2	0x00	0x42	0x01	0xAF	FUNCTION
48	PLUS	0xA2	0x00	0x43	0x01	0xAF	FUNCTION
49	MINUS	0xA2	0x00	0x44	0x01	0xAF	FUNCTION
50	SPLIT 4 CH	0xA2	0x00	0x45	0x01	0xAF	4 channel 8 channel 16 channel buttons
51	SPLIT 8 CH	0xA2	0x00	0x46	0x01	0xAF	4 channel 8 channel 16 channel buttons
52	SPLIT 16 CH	0xA2	0x00	0x47	0x01	0xAF	4 channel 8 channel 16 channel buttons

Communication Specification

* RS232 / RS485

* Baudrate : 2400bps ~ 57.6Kbps

* Start bit : 1bit

* Stop bit : 1bit

* Parity : None

Head Office

5436 W Crenshaw Street Tampa, FL 33634
Toll Free 866-446-3595 FAX 813-888-9262

Sales Office

9551 Irvine Center Dr
Irvine, CA 92618



Everything's Digital