

Camera Setup Quiz

1. How many ways can you control an analog camera's setup?
 - a. One, only after connecting the camera to a DVR
 - b. One, only using the menu button on the side of the module
 - c. Two using either the camera's menu button or the DVR's setup menu
 - d. Three, the menu button on the camera, the DVR's setup menu, and the IP configuration in the IP Finder
2. When connecting the PTZ camera to the remote controller, installer need-
 - a. Cable and terminal boxes
 - b. Only cable
 - c. Nothing, the PTZ39X connects to controller wirelessly
 - d. All of the above
3. Using the bank of options, organize in the correct order how to setup an IP camera-

Adjust camera's lens	Connect PoE cable to camera & PoE switch	Install & run IP Finder software	LED lights on indicating the camera is operating
Enter ID & Password (admin; admin)	Select camera and click connect	Mount camera to the wall	Configure, if necessary the camera's IP address

(Answers: 1. Mount camera/ 2. Connect Poe Cable/ 3. LED lights will come on/ 4.Adjust camera's lens/ 5. Install & run IP Finder software/ 6. Configure IP addresses if necessary/ 7. Select camera and click connect/ 8. Enter ID & Password (admin; admin))

4. When connecting the PTZ's power source, which of the following is the correct order of the positive and negative outlets?
 - a. Positive/ Ground/ Negative
 - b. Negative/ Ground/ Positive
 - c. Ground/ Negative/ Positive
 - d. Positive/ Negative/ Ground
5. When installing the IP Camera, what are the IP address options?
 - a. DHCP, PPPoE, DDNS, & Static IP
 - b. Static IP, DHCP, & PPPoE
 - c. Static IP & DDNS
 - d. DDNS, DHCP & PPPoE

