DW-MAX Firmware Upgrade

Upgrading the firmware can be done following these steps:

- Download ftp://ftp.dwcc.tv/Firmware/MAX/max_firmware.zip
- Open the folders and save the two firmware files to the root of your USB
- Insert the USB to the DW-MAX

(1) Log in to the Menu and click **ENTER**

DVR LOG-IN

USER ID	ADMIN
USER PW	_____

1 2 3 4 5 6 7 8 9

ENTER   EXIT

(2) Click **FIRMWARE UPGRADE**

MAIN MENU

DISPLAY SETUP
RECORD
CONFIGURATION
EXTERNAL DEVICE
BACK-UP
FIRMWARE UPGRADE
FACTORY DEFAULT

LANGUAGE   ENGLISH

                           EXIT

(3) Click **CHECK USB**
(4) Once the Upgrade is detected Click **UPGRADE**
(5) Once the Upgrade is complete reboot the DVR
(6) Enter any missing information on the DVR

FIRMWARE UPGRADE

CURRENT VER	10049 / V 2.00
UPGRADE VER	

CHECH USB   UPGRADE   ESC

If you need technical assistant please Call:866-446-3516 option#2