DW-MAX Network Setup (Static IP) Locally

(1) Log in to the Menu and click ENTER

DVR LOG-IN

USER ID   ADMIN
USER PW   _____

1   2   3   4   5   6   7   8   9

ENTER   EXIT

(2) Click on EXTERNAL DEVICE

MAIN MENU

DISPLAY SETUP
RECORD
CONFIGURATION
EXTERNAL DEVICE
BACK-UP
FIRMWARE UPGRADE
FACTORY DEFAULT

LANGUAGE   ENGLISH

EXIT

(3) Click on TCP/IP SETUP

EXTERNAL DEVICE

TCP/IP SETUP
PAN/TILT SETUP
MOUSE SETUP
AUDIO SETUP

ESC

(4) Click on IP SETUP

TCP/IP SETUP

IP SETUP
DDNS SETUP
BAUD RATE

ESC

IP SETUP	
MAC ADDRESS	00-0A-A2-00-FD-63
DHCP MODE	MANUAL
	IP DETECT
IP PORT	50000
IP ADDRESS	192.168.001.160
GATEWAY	192.168.001.001
SUBNET	255.255.255.255
	ESC

(5) Set **DHCP MODE** to **MANUAL**
(6) Enter the **IP ADDRESS**
(7) Enter the **GATEWAY**
(8) Enter the **SUBNET**
(9) Go out of MENU SETUP
(10) Reboot the Modem(Router)
(11) Wait 30sec after turning on Modem(Router)

**Static IP is provided by you ISP

If you need technical assistant please Call:866-446-3516 option#2

DW-MAX Network IP Setup (Static IP) Remotely

(1) Launch the software and click **NETWORK SETUP**

(2) Select a Site and click **REGISTERING SITE**

(3) Select **MANUAL**. Enter the IP Address, Port, User ID and Password. Click **OK**

(4) Select a Site and click **OK**

(5) Enter the password and click **LOGIN**

(6) Click on **LIVE**

If you need technical assistant please Call:866-446-3516 option#2

(7) Verify all the information is correct, then click **CONNECT**

(8) Once you see "CONNECTION ESTABLISHED" the video should load in a few minutes.